

ARMY CODE No:  
24044

AIR PUBLICATION  
5102 A (UH)



# AMBULANCE; 4 STRETCHER, 4x4, ROVER (with SPECIALIST EQUIPMENT)

USER HANDBOOK

March 1981

BY COMMAND OF THE DEFENCE COUNCIL

A handwritten signature in dark ink, appearing to read 'Frank Cuper', is positioned above the text 'MINISTRY OF DEFENCE'.

MINISTRY OF DEFENCE

PUBLICATIONS AUTHORITY

Quality Assurance Directorate (Ordnance)  
Publications Branch  
Royal Arsenal West  
Woolwich London SE18 6ST

U4553/1



### NOTES OF READERS

The subject matter of this publication may be affected by Defence Council Instructions, Emer Modifications Miscellaneous Instructions or General Orders and Modification Leaflets. If possible, amendments are issued to correct this publication accordingly. When an instruction or Leaflet contradicts any portion of this publication, the instruction or Leaflet must be taken as the overriding authority.

The lubricants and lubrication periods to be used will be those quoted in the Servicing Schedule or Air Diagram.

The information in this publication covers the following vehicles:

Ambulance, 4 stretcher, 4 x 4, Rover  
NSN2310-99-893-4673 AVC No 1054-0750

Ambulance, 4 stretcher, 4 x 4, LHD, Rover  
NSN2310-99-893-4674 AVC No 1054-5750

Ambulance, 4 stretcher, 4 x 4, Tropical, Rover  
NSN2310-99-893-5716 AVC No 1054-2750

Ambulance, 4 stretcher, 4 x 4, Tropical, LHD, Rover  
NSN2310-99-893-5717 AVC No 1054-6750

### WARNING

IN AMBULANCES DESIGNED FOR, BUT NOT YET EQUIPPED WITH, THE AUTOMATIC RESUSCITATOR SYSTEM (PAGE 23); USERS ARE WARNED NOT TO USE THE ASSOCIATED OXYGEN SYSTEM (PAGE 25). THIS WARNING IS GIVEN TO PREVENT POSSIBLE LEAKAGE OF OXYGEN FROM THE TEMPORARY BLANKING PLUGS FITTED TO THE ENDS OF THE OXYGEN PIPES IN READINESS FOR INSTALLATION OF THE AUTOMATIC RESUSCITATOR CONTROL BOXES.

## ASSOCIATED PUBLICATIONS

| ARMY  | Code No         |
|---|-----------------|
| Servicing Schedule .....                                | 61287           |
| Parts List .....  | 22726           |
| User Handbook (Rover 1 tonne chassis) .....             | 22260           |
| Complete Equipment Schedule .....                       | 31234           |
| <b>EMERS</b>  |                 |
| Resuscitator            Medical & Dental .....          | E 840-843       |
| Resuscitator Test Set            Medical & Dental ..... | Y 090           |
| Air Cooling (to be issued)                              |                 |
| Technical Handbook (chassis) .....                      | Wh Veh Q 052    |
| Technical Handbook (body) .....                         | Wh Veh Q 052/1  |
| RAF   | AP No           |
| Data Book of RAF Vehicles .....                         | 2782            |
| Manual for Mech Trans Servicing .....                   | 3260 Series     |
| RAF Engineering - Mech Trans .....                      | 1464E           |
| User Handbook (Rover 1 Tonne Chassis) .....             | AP5046A (UH)    |
| Technical Handbook .....                                | AP4590 (sect 1) |
| Refer to following AD's for Servicing:                  |                 |
| AD8287/1 issue 3  |                 |
| AD8288/B13 issue 2                                      |                 |
| AD8289/C1 issue 2                                       |                 |
| AD8289/C2 issue 3                                       |                 |
| AD8289/C8 issue 1                                       |                 |
| AD8290/     issue 1                                     |                 |

**CONTENTS**

|                               | Page |
|-------------------------------|------|
| Amendment record .....        | i    |
| Notes to readers .....        | ii   |
| Associated Publications ..... | iii  |
| Contents .....                | iv   |
| List of illustrations .....   | vii  |

**SECTION 1****GENERAL DESCRIPTION****Chapter**

|   |  |    |
|---|--|----|
| 1 | Introduction .....   | 1  |
|   | Data .....   | 1  |
|   | Special tools and equipment carried -<br>fitted to vehicle ..... | 1  |
|   | Medical equipment carried - Army role .....                      | 7  |
|   | Medical equipment carried - RAF role .....                       | 11 |
| 2 | Description of vehicle   |    |
|   | Body .....   | 15 |
|   | interior fittings and equipment                                  |    |
|   | Stretcher runners .....  | 16 |
|   | Casualty seats .....   | 17 |
|   | Attendant's seat .....   | 18 |
|   | Front cab seats .....  | 18 |
|   | Safety harness and restraint straps .....                        | 18 |
|   | Heating and ventilation .....                                    | 18 |
|   | Lighting .....   | 20 |
|   | Miscellaneous fittings .....                                     | 21 |
|   | Automatic resuscitation system .....                             | 23 |
|   | Oxygen system (WARNING) .....                                    | 25 |
|   | Air cooling system (RAF vehicles only) .....                     | 25 |
|   | Electrical system .....  | 26 |

**SECTION 2****OPERATING INSTRUCTIONS**

|   |   |    |
|---|---|----|
| 1 | General stowage locker .....                  | 31 |
|   | Spare wheel stowage .....                     | 31 |
|   | Battery stowage and battery replacement ..... | 31 |
|   | Rear folding steps .....                      | 32 |
|   | Escape hatch .....                            | 33 |

## CONTENTS - continued

| Chapter                                       | Page |
|---|------|
| Stretcher restraint straps ... ..             | 34   |
| Stretcher patient restraint ... ..            | 35   |
| Stretcher lift operation ... ..               | 36   |
| Seated patient restraint ... ..               | 37   |
| Stretcher stowage ... ..                      | 38   |
| Casualty compartment lighting ... ..          | 38   |
| Eberspacher heater ... ..                     | 39   |
| Air cooling system ... ..                     | 40   |
| Oxygen system ... ..                          | 41   |
| Entonox equipment ... ..                      | 41   |
| Air cooling system (RAF vehicles only) ... .. | 41   |

## Resuscitation system

|  |    |
|--|----|
| Using oxygen ... ..                            | 42 |
| Using air ... ..                               | 43 |
| Closing down the resuscitation system ... ..   | 44 |
| Changing oxygen cylinder ... ..                | 46 |
| Connecting and disconnecting face masks ... .. | 48 |
| Disassembling face mask valve ... ..           | 48 |

## SECTION 3

## USER SERVICING AND ADJUSTMENTS

|   |   |    |
|---|---|----|
| 1 | Lubrication ... ..                            | 51 |
|   | Changing lamps                                |    |
|   | Map reading light ... ..                      | 51 |
|   | Cab light ... ..                              | 52 |
|   | Casualty compartment light ... ..             | 52 |
|   | Casualty compartment blackout light ... ..    | 53 |
|   | Rotating beacon ... ..                        | 53 |
|   | Front fog light ... ..                        | 54 |
|   | Rear fog light ... ..                         | 55 |
|   | Rear compartment wander light ... ..          | 55 |
|   | Resuscitation system ... ..                   | 55 |
|   | Air cooling system (RAF vehicles only) ... .. | 55 |
| 2 | Special Instructions                          |    |
|   | Testing resuscitation system                  |    |
|   | General ... ..                                | 57 |
|   | Test procedure ... ..                         | 58 |

## CONTENTS - continued

| Chapter                                   | Page |
|---|------|
| Preparation for sea or air transportation | 59   |
| Slings points                             | 60   |
| Tie-down points                           | 60   |
| Do's and don'ts                           | 60   |

## SECTION 4

## DESTRUCTION OF EQUIPMENT

## General

|                            |    |
|----------------------------|----|
| Destruction                | 61 |
| Degree of damage           | 61 |
| Priorities for destruction | 61 |
| Spare parts                | 62 |
| Authority                  | 62 |
| Reporting                  | 62 |

## Methods of destruction

|            |    |
|------------|----|
| Mechanical | 62 |
| Burning    | 62 |
| Gunfire    | 63 |

## LIST OF ILLUSTRATIONS

| <i>Figure<br/>No</i> | <i>Description</i>                          | <i>Page</i> |
|----------------------|---|-------------|
| 1                    | Three-quarter front view .....              | 2           |
| 2                    | Three-quarter rear view .....               | 3           |
| 3                    | Back interior view .....                    | 9           |
| 4                    | Vehicle dimensions .....                    | 10          |
| 5                    | Instrument panel RH drive .....             | 12          |
| 6                    | Instrument panel LH drive .....             | 13          |
| 7                    | Heating and ventilation installation .....  | 19          |
| 8                    | ACU installation .....                      | 22          |
| 9                    | Resuscitation system .....                  | 24          |
| 10                   | Main circuit diagram .....                  | 27          |
| 11                   | Optional circuits diagram .....             | 28          |
| 12                   | Fuse and relay panel .....                  | 29          |
| 13                   | Battery stowage .....                       | 31          |
| 14                   | Unfolding rear steps .....                  | 33          |
| 15                   | Stretcher restraint .....                   | 34          |
| 16                   | Stretcher patient restraint .....           | 35          |
| 17                   | Stretcher lift operation .....              | 36          |
| 18                   | Seated patient restraint .....              | 38          |
| 19                   | Rear compartment control panel .....        | 39          |
| 20                   | Resuscitation system control unit .....     | 42          |
| 21                   | Norgren filters .....                       | 44          |
| 22                   | Oxygen cylinder regulator valve assembly .. | 47          |
| 23                   | Face mask valve .....                       | 49          |
| 24                   | Map reading light .....                     | 51          |
| 25                   | Cab light .....                             | 52          |
| 26                   | Casualty compartment light .....            | 53          |
| 27                   | Casualty compartment blackout light .....   | 53          |
| 28                   | Rotating beacon (alternative types) .....   | 54          |
| 29                   | Front fog light .....                       | 55          |
| 30                   | Resuscitation system test set .....         | 57          |



# **RESUSCITATION**

## **TREATMENT OF THE NON-BREATHING CASUALTY**

### **NOTICE**

The inclusion of the emergency resuscitation placard (MOD Form 656) in Military Technical Publications has been discontinued.

This notice is to be retained in the publication until removed by amendment instruction.

## Section 1

## General Description

## Chapter 1

INTRODUCTION

1. Apart from new front and rear shock absorbers, British Leyland UK Ltd. (Rover Part Nos NRC4394 (Front) and NRC4395 (Rear), the basic cab, chassis, suspension and chassis electrical equipment is identical to the Truck General Service, 1 Tonne 4X4 Rover, information on which is given in AP5064A (UH)/AC22260.
2. This publication gives information on the additional or alternative equipment fitted for the ambulance role.
3. The 1 Tonne Ambulance is designed to carry four stretcher patients or eight sitting patients and a medical attendant within an enclosed body mounted on a 1 tonne (Rover) chassis, and be of medium mobility.
4. The vehicle is available in either right or left-hand drive modes and is designed with a casualty compartment separated from the driver's cab. It can be fitted with Automatic Resuscitation equipment and/or Air Cooling equipment. A specially modified vehicle, fitted with Resuscitation equipment is available for the Airfield Crash Rescue Role. The driver's cab is provided with a single passenger seat.


DATA

## Vehicle Dimensions (Fig 4)

|                                     |                     |
|-------------------------------------|---------------------|
| Length                              | 4394mm (173 ins)    |
| Width                               | 2130mm (83 3/4 ins) |
| Height (unladen) - approximately    | 2500mm (98 ins)     |
| Height (with flasher beacon fitted) | 2690mm (106 ins)    |


## Internal dimensions

|  |                     |
|--|---------------------|
| Length (Bulkhead to Rear Doors)                                      | 2375mm (93 1/2 ins) |
| Height   | 1525mm (60 ins)     |
| Width  | 1975mm (77 3/4 ins) |
| Width (of centre gangway)  | 628mm (24 3/4 ins)  |
| Height - Top of Bottom Stretcher to<br>Bottom of Top Stretcher Frame | 460mm (18 ins)      |
| Height - Top of Top Stretcher to<br>Roof                             | 460mm (18 ins)      |



- |   |  |    |                          |
|---|--|----|--------------------------|
| 1 | Air intake (resuscitation vehicles only) | 6  | Heater air intake        |
| 2 | Escape hatch                             | 7  | Spare wheel stowage      |
| 3 | Hinged flap                              | 8  | Battery stowage          |
| 4 | Hinged flap                              | 9  | Engine air filter cover  |
| 5 | Stowage locker                           | 10 | Patient fresh air intake |

Fig.1 Three-quarter front view



1 Hinged flaps

2 Hinged flap

3 Fuel filler cap

Fig 2 Three-quarter rear view

## DATA (Contd.)

## Lamps

| Light              | Make                            | Watts | Volts | Type |
|--------------------|---------------------------------|-------|-------|------|
| Map reading        | Lucas Pt.No.<br>53837           | 6     | 12    | MCC  |
| Flashing beacon    |                                 | 21    | 12    | SBC  |
| Body               | FV959836                        | 21    | 12    | SBC  |
| Blackout           | BMAC 588                        | 5     | 12    | SBC  |
| Medical inspection | KELVIN NORTON                   | 24    | 12    | SBC  |
| Fog lamps (Front)  | Lucas Type PT8<br>Pt. No. 55349 |       | 12    |      |
| Fog lamps (Rear)   | Lucas Type<br>FV760752          |       | 12    |      |

## Fuses

| Location | Circuits | Type and rating |
|----------|----------|-----------------|
|----------|----------|-----------------|

## Block A

|   |  |                                   |
|---|--|-----------------------------------|
| 1 | Ignition switch Terminal 1   | Cartridge 35A<br>(17A continuous) |
| 2 | Auxiliary relay, Terminal C2<br>6-way lighting switch,<br>Terminal 6 Hazard warning switch,<br>Terminal +30 stop lamp switch | Cartridge 35A<br>(17A continuous) |
| 3 | Auxiliary relay, Terminal W1<br>Ignition switch, Terminal 2<br>Windscreen Wiper switch,<br>Terminal 4                        | Cartridge 35A<br>(17A continuous) |
| 4 | Warning lights connector<br>Ignition coil ballast resistor<br>Diff. Lock switch connector<br>Fuel content voltage stabilizer | Cartridge 35A<br>(17A continuous) |

## SPECIAL TOOLS AND EQUIPMENT (Contd.)

Carried (contd.)

| Item   | NATO Stock Number                       | Qty. |
|--|---|------|
| Spare wheel assy                                 |   |      |
| Comprising: Wheel disc 6.50L x 16 Rover NRC 0130 |   | 1    |
| Tyre 9.00 x 16 GMT14/2610-99-804-5425            |   | 1    |
| Tube inner 9.00 x 16 GMT14/2610-99-804-5822      |   | 1    |
| Spanner, wheel nut                               | 7RU/5120-99-817-1229<br>(Rover 1569687) | 1    |
| Handle starting                                  | Rover 595120                            | 1    |
| Jack lifting, triple screw                       | 6MT1/5120-99-825-4616<br>(Rover 592220) | 1    |
| Shaft (Metal handle)                             | Rover 543300                            | 1    |
| Shaft (Wooden lever)                             | Rover 543301                            | 1    |
| Pick, Head 2½ lb                                 | J1/5120-99-120-5933                     | 1    |
| Helve, pick 26 in                                | J1/5120-99-120-5934                     | 1    |
| Shovel G.S.                                      | J1/5120-99-120-7407                     | 1    |
| Camouflage, net (24 ft x 24 ft)                  |   | 1    |
| Key (Taper, T)                                   |   | 2    |

## MEDICAL EQUIPMENT CARRIED - ARMY ROLE

| Title   | NATO Stock Number  | Qt |
|---|--|----|
| Cup, Feeding  | J1/6530-99-120-4777  | 2  |
| Bed pan   | 6530-99-120-7832/21G   | 1  |
| Urinal, male patient  | 6530-99-129-6924/21G   | 1  |
| Blanket, single size, green   | 7210-99-120-6989/21  | 16 |
| Outfit, First Aid, large  | 9A/03360   | 1  |
| Pillow, stretcher, ambulance Mk.2   | KC/6530-99-129-1635  | 4  |
| Stretchers, ambulance Mk.2  | KC/6530-99-129-6837  | 4  |
| Broom, hand sweeping  | 7920-99-943-2803   | 1  |
| Con. plastic high density<br>polythene, 1 Gall  | 6MT1/7240-99-809-6628<br>(FV 959872)                               | 2  |
| Lamp inspection (Medical<br>attendant)  | FV959888<br>(Handy-Hook-a-Lite<br>Kelvin Norton<br>Pt. No. KN/HHL) | 1  |
| Resuscitator portable, folding<br>C/W two face pieces, in case                        | 6515-99-211-3516   | 1  |
| Airway, pharyngeal, size 1  | 6515-99-210-3025   | 1  |
| Airway, pharyngeal, size 2  | 6515-99-210-3026   | 1  |
| Airway, pharyngeal, size 3  | 6515-99-210-3027   | 1  |
| Suction apparatus, surgical,<br>foot operated - Cape, Lightweight                     | 6515-99-210-5635   | 1  |
| Sodium lactate compound injection<br>BP 1 litre disposable pack with<br>giving needle | 6505-99-210-2003   | 2  |
| Nexton 110 in NaCl injection<br>BP 1 litre disposable pack with<br>giving needle      | 6505-99-211-1600   | 2  |
| Footpiece and support, Thomas Leg<br>Splint metal adj. in width                       | 6515-99-210-7870   | 1  |
| Splint, Leg, Thomas, fixed ring<br>20 ins to 28 ins                                   | 6515-99-270-5588   | 1  |


ARMY CODE NO: 24044

AIR PUBLICATION 5102A(UH)

Medical (cont'd.)

| Title   | NATO Stock Number | Qty. |
|---|-------------------|------|
| Stretcher bar, leg splint supporting<br>with strap and buckle | 6515-99-210-7871  | 1    |
| Oxygen BP 44 cu ft in bull nosed<br>Valve cylinder            | 6505-99-942-3298  | 2    |
| Basin Emesis polypropylene 12 in<br>Kidney shaped             |                   |      |
| Regulator oxygen-fixed output<br>60 p.s.i. BOC Pt. No. S60-MG |                   |      |





- |   |   |
|---|---|
| 1 Squabs (Typical, 6 positions)   | 13 Upper stretcher stowage restraint strap (Typical, 4 positions) |
| 2 Stretcher stowage shelf (Typical, 2 positions)  | 14 Stretcher lift clamp (Typical, 4 positions)                    |
| 3 Upper stretcher lift assembly (Typical, 2 positions)  | 15 Blackout switch override                                       |
| 4 Stretcher buffer bracket (Typical, 8 positions)   | 16 Stretcher lifting handle                                       |
| 5 Oxygen probe adaptors (Typical, 2 positions)  | 17 Storage space (Typical, 2 positions)                           |
| 6 Infusion bottle hook (Typical, 4 positions)   | 18 Lower stretcher runner (Typical, 4 positions)                  |
| 7 Compartment light (Typical, 2 positions)  | 19 Lower stretcher restraint at 2 positions)                      |
| 8 Accessory panel   | 20 Water bottle stowage   |
| 9 Blackout light  | 21 Gangway storage locker   |
| 10 Attendant's seat   | 22 Contact breaker boxes (RAF vehicles only)                      |
| 11 Bulkhead cupboard (Typical, 2 positions ACU vehicles, 3 positions, resuscitation vehicles) | 23 Stretcher restraint strap (Typical, 8 positions)               |
| 12 Stretcher lift clamp (Typical, 4 positions)  | 24 Snatch plug (RAF vehicles only)                                |

Fig.3 Back interior view




Fig. 4 Vehicle dimensions

## MEDICAL EQUIPMENT CARRIED - RAF ROLE


## Note...

The following items are required to be carried or fitted to the ambulance in the Airfield Crash Rescue Role. These items are additional or alternative to those listed for the ambulance in the Army Role.

| Title   | NATO Stock Number | Qty |
|---|-------------------|-----|
| Analgesia apparatus,<br>Nitrous Oxide and Oxygen mixture,<br>Entonox (without cylinders)  | 6515-99-211-5080  | 1   |
| Nitrous Oxide BP 50% and Oxygen BP<br>50% .500 litre in pin indexed valved<br>cylinder, filled (for use with 6515-99-211-5080)              | 6505-99-211-5045  | 2   |
| First Aid Kit, Special Field Nurse  | 6545-99-211-4944  | 1   |
| Administering Set, Dextran, Plasma<br>Expanding, RAF pattern  | 6545-99-211-0709  | 1   |
| Resuscitator and Inhalator<br>Modulaire lightweight in carrying case<br>complete (This item similar to<br>6515-99-211-3516 under ARMY ROLE) | 6515-99-211-4180  | 1   |


## Note...

Stowages for analgesia apparatus and a gas cylinder is sited on the rear face of the bulkhead, either side of the central stowage locker. These stowages are only required on RAF vehicles, but all vehicles are fitted to accept stowages.



- |                          |                            |                            |
|--------------------------|----------------------------|----------------------------|
| 1 Map light switch       | 5 Heater control switch    | 9 Compressor clutch switch |
| 2 Lighting master switch | 6 Inspection light sockets | 10 Panel lights            |
| 3 Two-tone horn switch   | 7 Rear fog light switch    | 11 Resuscitation system    |
| 4 Rotating beacon switch | 8 Front fog light switch   | 12 Fuse and relay panel    |

Fig. 5 Instrument panel RH drive



- |                         |                    |                             |
|-------------------------|--------------------|-----------------------------|
| 1 Panel lights          | 5 Map light switch | 9 Heater control switch     |
| 2 Heater control switch |                    | 10 Inspection light sockets |

Fig.6 Instrument panel LH drive

ARMY CODE NO: 24044

AIR PUBLICATION 5102A(UH)

## Chapter 2

## Description of Vehicle

BODY

5. The body is fully enclosed and is of aluminium alloy and steel section throughout. The cab and casualty compartment is double skinned and is thermally insulated. The roof panel is a one piece construction of aluminium alloy sheeting capable of supporting the weight of one man when necessary.
6. The casualty compartment can be heated or cooled to suit local conditions. Adjustable outlets are positioned to provide an individual supply of cooled air to each of the four stretcher patients.
7. A number of stowage lockers are disposed about the compartment and for the Airfield Crash Rescue Role vehicle a battery charger and radio are fitted.
8. Full width double doors at the rear open 270° to engage with a catch on their respective body sides and when closed are secured by spring loaded shoot-bolts.
9. The shoot-bolts are released by lever type handles. The right hand door has two handles, an internal and a lockable external. The left hand door has an internal handle only and when closed is further secured by the right hand door, which overlaps. For this reason the left hand door must be closed first.
10. Communication between driver's cab and casualty compartment can be made through sliding windows either side of the full height centre locker. All windows can be blacked out.
11. Access to the casualty compartment is by a folding step mounted at the rear, which folds away flush to the rear of the body when not in use.
12. Three external lockers (Fig 1) are provided on the left hand side of the body. The forward locker (7) houses the spare wheel. The rear locker (5) is for the stowage of tools. A third lower locker (8) contains the vehicle battery. A slave battery is also carried in this locker for vehicles in use with the ROYAL AIR FORCE.

INTERIOR FITTINGS AND EQUIPMENT

13. The main stowage space is provided by a full height centre locker (Fig 3 (11)) and at the foot of this locker beneath the attendant's seat (10) a recess gives space for the stowage (20) of a water container.

14. Other lockers (17), provided each side of the centre gangway at the rear of the wheel arches, are used for the stowage of stretcher lift winding handles (16), patient restraint straps and for an additional water container. Access to each stowage area is through an opening in the top panel of the wheelbox, between the rear ends of the lower stretcher runners.
15. An open stowage, between the bulkhead and the forward face of the wheel-arch, on the right-hand side of the casualty compartment houses two 44 cu ft oxygen cylinders. The cylinders are secured by two clamping bars which can be released by unscrewing two clamping screws. Vehicles fitted with Air Cooling equipment are supplied with bull-nosed valves, pressure gauge and connections attached to the cylinders. In vehicles fitted with Resuscitation equipment the oxygen is piped from the cylinders to the Resuscitation control boxes.
16. On the left-hand side of the vehicle, in the casualty compartment, below the stretcher runners and inboard of the wheel-arch, a locker with two sliding doors is fitted. The doors provide access from the gangway, and when closed are secured by magnetic catches.
17. The corresponding space on the right-hand side of the casualty compartment is left open to provide storage space for two stretchers. A restraint strap is provided at the forward and rear ends of the stowage area to secure the stretchers.
18. A shelf is provided along each top side of the casualty compartment. Each shelf is fitted with a forward and aft restraint strap and provides stowage for one stretcher.
19. Forward of the bulkhead a stowage locker is located behind the right hand seat. The locker is a hinged flap and is secured when closed by a spring-loaded catch. The locker stores accessories for the Thomas Leg Splint. The splint is stowed in brackets on the forward face of the bulkhead, above and behind the driver and passenger's seats in vehicles fitted with air cooling equipment.
20. A Standard Vehicles First Aid Kit is stowed on top of the fresh air intake above the cab door on the right-hand side.

#### Stretcher Runners

21. Stretcher runners of mild steel channel are positioned longitudinally inside the casualty compartment, in tiers, two either side of the gangway. The lower stretcher runners are fixed to the upper face of the wheel box structure, but the outboard runners are easily removed to gain access to the upper stretcher lift mechanism.



22. The upper stretcher runners form part of the stretcher lift frame, which is capable of supporting the stretcher and patient throughout the lift/lower cycle. In the two stretcher, or sit patient roles, the lift frame is fully lowered and rests on the lower stretcher runners. This is also the normal loading position.
23. A stretcher lift mechanism is installed on each side of the casualty compartment. The lift moves vertically when the screw gear is operated. The screw gear is installed between the outboard lower stretcher runner and the body on either side of the vehicle. The screw gear terminates in a square ended shaft, which is accessible when the rear doors are open. The lift mechanism is operated by a detachable handle.
24. In the raised position each stretcher lift is locked in position by two robust, quick action clamps located at the top of forward and rear faces of the lift mechanism housing panels. The clamps are double pressure over-centre type locks which when applied lock into the stretcher lift frame. The stretcher lift is further supported in the upper position by a robust, quick action clamp, fitted at the forward and rear ends of the inboard upper stretcher runner. These clamps when applied, engage serrated plates mounted on the vehicle body structure.
25. Two quick release tie-down straps are provided for each stretcher, to secure the stretchers, when in use, against vertical and longitudinal movement. One end of a strap is permanently attached to either end of the outboard stretcher runner, the other end hooks into a hole in the inboard stretcher runner. The belt can be tensioned or released by a quick release buckle.
26. Two patient restraint straps are provided for use with each stretcher. The straps are quick release type and can be fitted in a variety of positions along the length of the stretcher runner.

#### Casualty Seats

27. A seat cushion for sitting patients is provided to fit within each upper stretcher frame. The cushions are of latex foam mounted on a plywood base and covered with PVC leathercloth. Each cushion is provided with a wide strip of webbing, positioned centrally along the length of the face to prevent snagging by the stretcher underframe.
28. Back rests of similar construction are mounted on the side wall of the casualty compartment adjacent to the seat cushions. The seat cushions and back rests are readily detachable for cleaning and decontamination.

Attendant's Seat

29. The attendant's seat cushion is of similar construction to the patients' seat cushions and is fitted onto the base structure. The seat is hinged along its left hand edge to provide access to an area suitable for the storage of small items.

30. A seat back rest and headrest of similar construction to the patients' back rests, are fitted centrally on the bulkhead locker. Each rest is mounted on a hinged locker flap and is easily removed for cleaning and decontamination.

Front Cab Seats

31. The Driver and Passenger seats in the cab are provided with the chassis and are described in the Users' Handbook for the standard 1 Tonne Rover.

Safety Harness and Restraint Straps

32. Lap/diagonal type safety harnesses are provided with the chassis for the driver and passenger.


33. An inertia reel type lap belt is fitted to provide for restraint of the attendant during cross-country transit. The belt is designed to be capable of being operated with one hand.

34. Eight, semi-permanent, quick release patient restraint straps are provided for securing stretcher patients in transit. These straps can also be utilized as lap straps to restrain seated patients when required. The straps attach to the outboard stretcher runners.

Heating and Ventilation

35. The cab heating and demisting system is incorporated with the engine cooling system. A ducting on the engine cover is extended rearwards to provide a primary level of heating and ventilation in the casualty compartment. The rate and/or direction of flow is controlled by an outlet in the attendant's seat structure.

36. A secondary form of heating (Fig 7) in the form of an Eberspacher B4L 12V petrol burning heater unit (6) is installed in a sealed locker, behind the left-hand seat in the driver's cab. The heater is ducted into the casualty compartment, via the bulkhead, to the base of the attendant's seat, which is fitted with a floor level grille to deflect the flow of hot air away from the attendant's feet.



- |  |                             |
|--|-----------------------------|
| 1 Patient fresh air filters                          | 5 Eberspacher heater outlet |
| 2 Fresh air blower                                   | 6 Eberspacher heater        |
| 3 Patient fresh air outlet<br>(Typical, 4 positions) | 7 Eberspacher heater inlet  |
| 4 Engine heated air outlet                           | 8 Re-circulating air vent   |
|  | 9 Fresh air blower          |

Fig. 7 Heating and ventilation installation


37. A fresh air inlet (7) to the heater is provided by an externally mounted louvred panel in the left-hand side of the cab immediately aft of the cab door. Provision is made to enable the fresh air intake to be closed and the air within the casualty compartment recirculated via an intake (8) and ducting built into the bulkhead.
38. The external fresh air intake is fitted with a filter which can be removed for cleaning.
39. The heater controls are mounted in the driver's cab within reach of the driver. In addition, an adjustable thermostatic control unit is located in the top right hand corner of the bulkhead locker, for operation by the attendant.
40. Fresh air is provided for each stretcher patient. The air is ducted from louvres, one each side of the vehicle above the windscreen, to four outlets on the bulkhead. The air outlets are positioned adjacent to each stretcher patient (3) and can be adjusted for direction and rate of flow. Two blower units (2 and 9) are fitted to maintain airflow when the vehicle is stationary. Baffles and drain holes are suitably positioned within the system to prevent accumulation and 'carry over' of water through the ducting.

#### Lighting

41. General illumination of the casualty compartment is provided by two ceiling mounted light units. The intensity of the light emitted is controlled by a pair of switches mounted in the top left hand corner of the bulkhead locker. A low intensity blue blackout light (Fig 3 (9)) is provided to illuminate the casualty compartment when loading under combat conditions.
42. Opening the rear doors whilst the white (normal) lights (7) are on, will automatically extinguish the normal lights and switch on the blackout light. To enable the normal light to remain 'ON' with doors open during loading under non-combat conditions an overriding device (15) is fitted. The overriding device comprises a steel plate which can be repositioned to hold in the plunger of a micro-switch. The microswitch is located at the top right hand corner of the rear door aperture.
43. A portable lamp complete with electric lead is provided for examination of patients. A socket point and control switch are fitted in the top of the bulkhead locker.
44. Illumination in the driver's cab is provided by a light unit mounted centrally above the windscreen and a map reading lamp on the fresh air ducting above the outboard of the passenger's seat.

Miscellaneous Fittings

45. Support hooks for infusion bottles (6) are provided in the compartment at four positions (two forward, two aft), conveniently located for the treatment of each stretcher patient. When not in use the support hooks fold flush to maintain a protrusion free ceiling in the casualty compartment.
46. In the driver's cab a rigid panel fitted between the driver and passenger's seats, has weapon clips mounted on its top edge for the stowage of one SLR. Sun visors for the driver and passenger are mounted above the windscreen.
47. Stowages for the two 'T' keys used to open external lockers are provided. One stowage is located within the driver's cab on the right hand side wall behind the seat, the other stowage is on the right hand rear door. Both stowages are within easy reach of a person standing outside the vehicle.
48. The oxygen supply is piped from one of the two cylinders located below the right hand lower stretcher, to two outlet points, one on either side of the bulkhead locker conveniently located for use by the upper or lower stretcher patient. On vehicles fitted with Air Cooling Equipment (Fig 8) the supply is piped direct from the cylinders via a regulator valve attached to the cylinders to quick release couplings. The quick release couplings mounted on the bulkhead provide the method of connecting face masks to the system.
49. A cylinder operating key and a spanner for connecting the regulator valve are stowed on the bulkhead adjacent to the cylinder heads. New issue regulators are provided with a hand nut for connection and do not require the use of the spanner.



1 Condenser  
2 Control switches

3 Filter unit

4 Evaporator  
5 Compressor

Fig.8 ACU Installation

AUTOMATIC RESUSCITATION SYSTEM

50. The automatic resuscitation system (Fig 9) enables the medical attendant to initiate and maintain positive-pressure artificial respiration to nerve agent casualties. Provision is made for the simultaneous treatment of up to four casualties.

51. Provision is made for the distribution of a pulsating supply of either air or oxygen at a pressure of 4.0 bar (60 lbf/sq in) to face masks at the patients' position.


52. Air supply for the system is via an inlet on the front top of vehicle, through a filter box (1) in the roof of the driver's cab, a compressor (9) driven by a fan belt off the vehicle's engine to air reservoir (6) mounted under the floor on the left-hand side of the vehicle. The reservoir is maintained at a maximum working pressure of 7.1 bar (100 lbf/sq in). A governor valve (8), mounted inside the heater compartment of the left-hand side of the vehicle ensures that the reservoir pressure does not rise above its maximum working pressure and also acts as a cut-in to operate the compressor when the reservoir pressure falls to less than 6.2 bar (90 lbf/sq in). The compressor is controlled by a magnetic clutch, initially engaged by a switch on the cab instrument panel.

53. From the reservoir, pressurized air is passed via Norgren filters (2) mounted in the driving cab, to two automatic resuscitation control units (3 and 12) mounted on the bulkhead separating the driving cab from the rear compartment. The pulsating supply at the reduced pressure of 4.0 bar (60 lbf/sq in) is distributed to the face masks (4) from the control units. A low pressure warning switch, incorporated into the output side of the system, operates a low pressure warning buzzer, mounted on the fuse box and relay panel in the driver's cab, whenever the output pressure falls below 4.0 bar (60 lbf/sq in). The buzzer continues to operate until the pressure has risen above 4.0 bar (60 lbf/sq in).

54. The Norgren filter unit comprises two filters and a non-return valve. Air passes into the first filter element where it is cleared of any oil or other contamination. From the first filter element air passes through the second, where any odours still present in the air are removed. The non-return valve prevents air or oxygen re-entering the filters and thus becoming contaminated again.

Note...

If an odour is detected in the filtered air, this is an indication that the carbon cartridge filter requires replacement. However, this does not mean that the air is contaminated and is still quite breathable.



- |   |                 |    |                          |
|---|-----------------|----|--------------------------|
| 1 | Filter box      | 7  | Air reservoir vent lever |
| 2 | Norgren filters | 8  | Governor valve           |
| 3 | RH control unit | 9  | Compressor               |
| 4 | Face masks      | 10 | Low pressure valve       |
| 5 | Oxygen cylinder | 11 | Air pressure gauge       |
| 6 | Air reservoir   | 12 | LH control unit          |

Fig.9 Resuscitation system



## OXYGEN SYSTEM

## WARNING

IN AMBULANCES DESIGNED FOR, BUT NOT YET EQUIPPED WITH THE AUTOMATIC RESUSCITATOR SYSTEM (PAGE 23); USERS ARE WARNED NOT TO OVERTIGHTEN THE OXYGEN SYSTEM. THIS WARNING IS GIVEN TO PREVENT POSSIBLE LEAKAGE OF OXYGEN FROM THE TEMPORARY BLANKING PLUGS FITTED TO THE ENDS OF THE OXYGEN PIPES IN READINESS FOR INSTALLATION OF AUTOMATIC RESUSCITATOR CONTROL BOXES.

55. The oxygen system is supplied from cylinders, installed below the right-hand stretcher rack. Two cylinders are installed, but only one is in use at any one time. The cylinder in use has a pressure regulator fitted to the neck.

56. On non-resuscitation system vehicles, the oxygen is piped to two probe adapters, one on each side of the front bulkhead of the rear compartment. When the resuscitation system is installed, the oxygen supply is piped to the two automatic resuscitator units. The output pressure from the cylinder is regulated at 4.0 bar (60 lbf/sq in) by a pressure regulator, which is pre-set by the manufacturer and under no circumstances should the regulator be tampered with.

## AIR COOLING SYSTEM (RAF vehicles only)

57. The air cooling system (Fig 8) is fitted to certain vehicles operating in tropical climates. The system provides a supply of cooled air to the rear compartment. The degree of cooling is controlled by a thermostat. Air can also be re-circulated with further cooling by operation of an independent fan control.

58. The condenser (1), which cools the refrigerant agent and converts it from a gas to a liquid is mounted in a duct assembly located in the driver's cab roof. The cooling medium is ram air which enters the duct via a mesh grille on the front face of the duct above the windscreen.

59. A filter drier (3) is fitted in the system between the condenser and the expansion valve and is mounted on the forward face of the bulkhead above the vehicle's electrical control housing. The filter removes any traces of oil, water or foreign matter from the liquid refrigerant. A sight glass on the top of the filter allows constant monitoring of the refrigerant when the system is operating.

60. The evaporator (4) is located in the base of the rear compartment bulkhead cupboard and is accessible through a large panel forward of the attendant's seat. Cooled air is ducted to louvred outlets at each casualty position via a blower motor which is mounted on top of the evaporator assembly.

61. The system is controlled by three switches:

- a Compressor control switch. This is a push/pull switch mounted on the instrument panel. Operation of the switch energises the electro-magnetic coil and the compressor is driven, provided that the temperature in the compartment is higher than the temperature set on the thermostat control.

b. Temperature control. This is a rotary switch, mounted on the rear face of the front bulkhead of the rear compartment and is used to control the temperature of the air output.

c. Fan control. This is a 4-position rotary switch; the positions are OFF, H(igh), M(edium) and L(ow). The switch controls the speed of the fan and can be used independently of the temperature control so that air can be re-circulated without cooling.

### ELECTRICAL SYSTEM

62. The electrical system is a standard 12V negative earth system as fitted to the basic 1 Tonne vehicle with the following modifications:

a. The existing 16 ACR alternator has been removed and replaced by a 25 ACR alternator with associated chassis rewiring.

b. The NATO 12 pin socket has been removed from the rear of the chassis and associated lead ends insulated and stowed.

c. The original battery and stowage behind the passenger seat has been removed.

63. The resighted battery together with a second 'Slave' battery is installed in a locker beneath the chassis on the left-hand side of the vehicle body.

a. The slave battery is of the same type and rating as the vehicle battery and is provided to meet the additional electrical loads of the ambulance role.

b. The batteries are mounted on sliding trays and are readily accessible. The stowage locker is provided with drain holes and ventilated to atmosphere outside the vehicle.

c. Both batteries can be maintained in a fully charged state by use of a split charging system.

64. The additional electrical circuits for the ambulance role are shown in the wiring diagram. Royal Air Force vehicles are equipped with an engine immersion heater, mains battery charger, snatch plug, earth leak circuit breaker installation, radio and a slave battery.



27





Fig. 11 Optional circuit - 411111



- |   |   |    |                         |
|---|---|----|-------------------------|
| 1 | Fuse block 3  | 5  | Horn relay B            |
| 2 | Compressor clutch relay<br>(resuscitation vehicle) or ACU<br>clutch relay (RAF vehicle) | 6  | Horn control (3)        |
| 3 | Rear fog light relay  | 7  | Air low pressure buzzer |
| 4 | Terminal block  | 8  | Horn isolation relay A  |
|   |   | 9  | Inline diodes           |
|   |   | 10 | Horn relay A            |
|   |   | 11 | Fuse block 2            |

Fig 12 Fuse and relay panel

ARMY CODE NO: 24044

AIR PUBLICATION 5201A(UH)

## Section 2

## Chapter 1

## Operating Instructions

GENERAL STOWAGE LOCKER


65. The general stowage locker, located just forward of the rear wheel arch on the left-hand side of the vehicle is secured by a lock operated by a T-bar, which is stowed in the driver's cab. The locker is opened by inserting the T-bar into the lock and rotating to release. Closing is achieved by lifting the flap and engaging the locks, if necessary by rotating the T-bar.

SPARE WHEEL STOWAGE

66. The spare wheel is stowed in a compartment forward of the general stowage locker on the left-hand side of the vehicle. Opening and closing is similar to the general stowage locker and the same T-bar is used.

BATTERY STOWAGE AND BATTERY REPLACEMENT

67. The battery stowage (Fig 13) is directly below the spare wheel stowage. The batteries are mounted on trays (3) which slide in and out on rails to facilitate battery replacement. The procedure for replacing a battery is as follows:-



- 1 Locking pin
  - 2 Battery securing frame
  - 3 Battery tray
- Fig. 13 Battery stowage

- a. Open the stowage flap using the T-bar (para.65).
- b. Pull out the locking pin (1) from the centre of the battery tray and withdraw tray from compartment.
- c. Disconnect the positive and negative leads from the battery terminals.
- d. Unscrew the wing nuts and remove the battery securing frame (2). Remove the battery from the tray.
- e. Place the replacement battery on the tray. Position the securing frame over the battery and secure by tightening the wing nuts.
- f. Connect the positive and negative leads to their respective terminals on the battery.
- g. Push the tray back into the battery compartment and secure with the locking pin.
- h. Close the compartment flap.


#### REAR FOLDING STEPS

68. The rear folding steps (Fig 14) can be operated from either inside or outside the vehicle. The procedure is as follows:-

**WARNING...**

**PERSONNEL ARE TO REMAIN WELL CLEAR TO EITHER SIDE WHEN FOLDING OR UNFOLDING IS IN PROGRESS**





- a. Unfolding from outside
  - (1) Release the shoot bolts
  - (2) Stand to one side of the step and pull rearwards, allowing steps to hinge downwards
  - (3) Pull down the lower hinged tread.
- b. Unfolding from inside
  - (1) Release the shoot bolts
  - (2) Push the steps outwards and downwards and allow to fall
  - (3) Push down the lower hinged tread.
- c. Closing
  - (1) Pull and lift either corner of the back panel at the position indicated on the panel.

Note...

The lower tread is self-folding and may close in one movement.

- (2) Ensure that the lower hinged tread is fully folded then lock the steps with the shoot bolts

#### ESCAPE HATCH

69. The escape hatch (Fig 1(2)) may be removed from either inside or outside the rear compartment. To operate, proceed as follows:-

- a. External removal
  - (1) Rotate the winged fastener securing both covers on the top of the hatch and raise the covers
  - (2) Rotate both handles in the direction indicated
  - (3) Lift the hatch clear of the opening.
- b. Internal removal
  - (1) Rotate both handles in the roof of the rear compartment in the direction indicated
  - (2) Push the hatch upward clear of the opening and project to one side.

Fig.14 Unfolding rear steps

c. Hatch fitment


- (1) Ensure both handles are turned to the release position
- (2) Position the hatch in its opening in the roof
- (3) Rotate both handles to the closed position, then check that the hatch is secure.

STRETCHER RESTRAINT STRAPS

70 Restraint straps (Fig 15) for securing the stretcher after it has been placed on the runners are permanently attached to the outer high flanges of the runner. The method of use is as follows:-

Note...

Each strap incorporates a large metal load-lok buckle and must not be used for patient restraint.



a. Securing a stretcher.

- (1) Position the straps over the handles of the stretcher and insert the wire hook on the free end through the hole in the flange of the runner
- (2) Shorten the strap as required by lifting the arm of the buckle and feeding the free end of the strap through the buckle
- (3) Tension the straps fully by pushing the arm of the buckle over-centre and flat down.

b. Releasing a stretcher

- (1) Release the tension on the strap, by pulling the arm of the buckle up and over the vertical position
- (2) Loosen the straps by pushing back through the buckle
- (3) Release the hook from the hole in the runner and lift the strap clear of the stretcher.

Fig.15 Stretcher restraint

STRETCHER PATIENT RESTRAINT

71. Provision is made for the restraint of a patient on a stretcher once the stretcher has been placed on the runners. Two straps are provided for each stretcher (Fig 16). The procedure is as follows:




Fig.16 Stretcher patient restraint

a. Patient restraint

- (1) Select the most suitable position in regard to the injuries of the casualty and secure the strap to the outer flange of the runners by means of the snap hook incorporated into one end of the straps through the nearest suitable hole
- (2) Pass the strap over the patient and secure to inner stretcher runner, by passing the wire hook through the nearest suitable hole or slot in the runner
- (3) Pull the face end of the strap through the plastic buckle to tension the strap
- (4) Repeat the procedure at a suitable point with the other strap.

b. Patient release

- (1) Press the tongue protruding from the centre of the buckle and ease the straps open sufficiently to enable the wire hooks to be released.
- (2) Release the wire hooks and pass the freed end of the strap over the patient
- (3) Unclip the snap hook and remove the strap
- (4) Repeat the procedure for the other strap.

STRETCHER LIFT OPERATION

72. To raise a stretcher to the upper position on either side, proceed as follows:-

- a. Ensure that the stretcher lift is in the fully lowered position, by fitting the handle to the squared shaft (Fig 17) immediately outboard of the outer runner and rotating the handle counter-clockwise.
- b. Load the stretcher on to the runners so that the stretcher handles just touch the buffers mounted on the forward bulkhead of the rear compartment.




Fig.17 Stretcher lift operation

- c. Secure the stretcher in position with the restraint straps (refer to para.70).
- d. As necessary, restrain the patient on the stretcher (refer to para.71).
- e. Fit the handle to the appropriate square shaft and rotate clockwise to raise the stretcher.

Note...

When the stretcher has reached its maximum height, the lift will be felt to abutt its stops. Do not attempt to turn the handle beyond this point.

- f. Apply the transit clamps at the top of the lift column, then at the forward and aft ends of the stretcher runners to secure the lift.

Note...

The levers are of the over-centre type and a first and second pressure must be felt to ensure that the clamp is positively locked.

- g. Remove the handle and re-stow the handle in the rear compartment.

STRETCHER PATIENT RESTRAINT

71. Provision is made for the restraint of a patient on a stretcher once the stretcher has been placed on the runners. Two straps are provided for each stretcher (Fig 16). The procedure is as follows




Fig.16 Stretcher patient restraint

a. Patient restraint

- (1) Select the most suitable position in regard to the injuries of the casualty and secure the strap to the outer flange of the runners by means of the snap hook incorporated into one end of the straps through the nearest suitable hole
- (2) Pass the strap over the patient and secure to inner stretcher runner, by passing the wire hook through the nearest suitable hole or slot in the runner
- (3) Pull the face end of the strap through the plastic buckle to tension the strap
- (4) Repeat the procedure at a suitable point with the other strap.

b. Patient release

- (1) Press the tongue protruding from the centre of the buckle and ease the straps open sufficiently to enable the wire hooks to be released.
- (2) Release the wire hooks and pass the freed end of the strap over the patient
- (3) Unclip the snap hook and remove the strap
- (4) Repeat the procedure for the other strap.

# STRETCHER LIFT OPERATION

72. To raise a stretcher to the upper position on either side, proceed as follows:-

- a. Ensure that the stretcher lift is in the fully lowered position, by fitting the handle to the squared shaft (Fig 17) immediately outboard of the outer runner and rotating the handle counter-clockwise.
- b. Load the stretcher on to the runners so that the stretcher handles just touch the buffers mounted on the forward bulkhead of the rear compartment.




Fig.17 Stretcher lift operation

- c. Secure the stretcher in position with the restraint straps (refer to para.70).
- d. As necessary, restrain the patient on the stretcher (refer to para.71).
- e. Fit the handle to the appropriate square shaft and rotate clockwise to raise the stretcher.

**Note...**

When the stretcher has reached its maximum height, the lift will be felt to abutt its stops. Do not attempt to turn the handle beyond this point.

- f. Apply the transit clamps at the top of the lift column, then at the forward and aft ends of the stretcher runners to secure the lift.

**Note...**

The levers are of the over-centre type and a first and second pressure must be felt to ensure that the clamp is positively locked.

- g. Remove the handle and re-stow the handle in the rear compartment.

73. To unload a stretcher, proceed as follows:-

- a. Fit the handle to the appropriate squared shaft.
- b. Release the forward and aft clamps and then the centre clamp to unlock the lift assembly.
- c. Rotate the handle counter-clockwise to lower the lift assembly.

Note...

If the stretcher is empty when being lowered, ensure that the buckles of the stretcher restraint straps do not become trapped under the stretcher runners.

- d. If the stretcher is not to be lowered to the fully lower position, continue to rotate the handle until the stretcher is lowered to the required position, then lock with the centre clamp then the forward and aft clamps.
- e. When the stretcher is lowered to the required position, remove and stow the handle.

#### SEATED PATIENT RESTRAINT

74. In the seat patient role (Fig 18), the stretcher patient restraint straps may be utilized as lap straps. The procedure for use is as follows:-

- a. Select the most suitable position and engage the snap hook in the flange of the outer stretcher runner.
- b. Pass the strap across the patient's lap and engage the wire hook in an adjacent hole in the flange of the outer stretcher runner.
- c. To tighten the strap, pull the free end through the buckle.
- d. To release the patient:-
  - (1) Press the tongue protruding from the centre of the buckle, then ease the strap back through the buckle
  - (2) Release the wire hook from the hole in the flange.

Note...

The patient restraint straps are supplied as part of the vehicle equipment and must be retained with vehicle at all times.




Fig.18 Seated patient restraint

#### STRETCHER STOWAGE

75. When not in use the four stretchers are to be removed from their respective runners and stowed in a folded condition in the stowage provided in the casualty compartment. Two stretchers are stowed on the floor at the base of the right hand stretcher support box, the other two stretchers are stowed at roof level on the shelf. In position the stretchers are secured by adjustable straps which are permanently attached to the vehicle structure one at each end of the stretcher stowages. The free end of each lower strap is hooked into a staple mounted on the floor, the free end of each upper strap is hooked into a slot in the shelf. The strap can be tightened by pulling the tongue of the strap through its buckle or slackened by pressing the protruding tongue in the centre of the buckle and easing the strap through the buckle.

#### CASUALTY COMPARTMENT LIGHTING

3. All lighting in the casualty compartment is controlled by a master switch (Fig 5(2)) located on the auxiliary switch panel in the driver's cab. Within the casualty compartment two main lamp units controlled by two switches (Fig 19(1)) provide four levels of illumination. The levels of lighting are as follows:-

- a. One switch UP - one light on DIM
- b. Two switches UP - both lights on DIM




c. One switch UP, one switch DOWN - one light DIM, one light BRIGHT

d. Two switches DOWN - both lights BRIGHT

Note...

With both switches in the centre position both lights will be off.



1 Light switches

2 Wander light socket

3 Socket switch

4 Thermostat

Fig.19 Rear compartment control panel

### EBERSPACHER HEATER

77. The level of heat in the casualty compartment is controlled entirely by the thermostat. The heater can be used to supply fresh air at ambient temperature by adjusting the controls to its lowest setting. To operate the heater proceed as follows:-

a. Start-up

- (1) Set thermostat to the required level
- (2) Pull the switch (Fig 5(5)) on the auxiliary panel out to its first stop, the pilot light illuminates and the blower fan will start.

Note...

No further action is necessary if ventilation only is required.

- (3) Pull the switch out to its second stop, the feed pump will start (ticking sound) and the heater will ignite.

WARNING...

IF THE HEATER FAILS TO IGNITE DO NOT ATTEMPT TO SWITCH THE HEATER ON MORE THAN TWICE MORE. IF THE HEATER FAILS TO IGNITE AT THE THIRD ATTEMPT - REPORT.

Note...

The heater normally draws its air supply from outside the vehicle, but if a rapid warm-up of the casualty compartment is required closure of the inlet panel louvre will re-circulate casualty compartment air through the heater. The inlet closing control is a lever fitted on the left hand side of the heater compartment.

CAUTION...

The intake grill for re-circulating air is situated in the top left hand corner of the casualty compartment bulkhead and is to be kept free of obstructions.

b. Shut-down

- (1) Push the switch on the auxiliary panel fully in to the 'OFF' position.

Note...

The pilot light will extinguish and the blower fan will continue to run for a short time to cool the heater and then switch off automatically.

- (2) Check that the system has shut down before leaving the vehicle.

AIR COOLING SYSTEM

78. The air cooling system (Fig 8) is operated by two controls located on the casualty compartment locker, a blower fan switch and a thermostat. The system is supplied with air by an engine driven compressor which is engaged when the blower control and thermostat are switched on. A hand throttle control is provided on the centre of the engine cover for use when the vehicle is stationary. The stop position of this throttle is pre-set.

Note...

Should adjustment of the throttle stop become necessary, the engine r.p.m. should be adjusted to between 1000-1250 r.p.m.

To operate proceed as follows:-

- a. Start-up
  - (1) Start the vehicle engine
  - (2) Set blower fan control to the required rate of air flow
  - (3) Set thermostat to give required degree of cooling.

Note...

Although not essential, setting the system controls to 'OFF' whenever the vehicle engine is not running will ensure that the vehicle starter is not overworked when re-starting the engine.

### OXYGEN SYSTEM

79. The vehicles fitted with the resuscitation system the oxygen supply to the patient is piped via the resuscitation control unit. In vehicles fitted with the air conditioning system the oxygen is supplied to the patient via a face mask connected to a control valve in the oxygen cylinder neck. The control valve regulates the supply pressure at 4.0 bars (60 lbf/sq in) when the cylinder is opened with the bottle key. The bottle key is stowed in the right hand lower stretcher support box.

### ENTONOX EQUIPMENT

80. Two 500 litre Entonox cylinders are supplied complete with face masks, valves and flexible pipelines for use in RAF vehicles only. The cylinders are stowed in brackets mounted on each side of the bulkhead compartment.

### WARNING...

OPERATION OF ENTONOX EQUIPMENT IS THE SUBJECT OF SPECIAL INSTRUCTIONS AND WITHOUT THESE THE EQUIPMENT MUST NOT BE USED.

### AIR COOLING SYSTEM (RAF vehicles only)

81. To cool the rear compartment as quickly as possible, proceed as follows:-

- a. Close all fresh air vents.
- b. Set TEMP control to coldest setting.
- c. Set FAN control to H(High speed).
- d. Open a window for a few minutes to allow the hot air to be expelled quickly.
- e. Close the window and adjust controls to the desired speed and temperature.

- d. Check that a supply of oxygen is reaching the required face masks by placing a hand over the mask and feel for gas pulsations.
- e. Set the control lever on the control box(es) to OFF until required for use.
- f. When ready for use, set the control lever(s) to OXYGEN and place the face mask over the patient's nose and mouth.

#### Using Air

83. To operate the system, proceed as follows:-

#### Note...

The air reservoir and Norgren filters should have been drained after the system was last in use.

- a. Ensure that all drain valves are closed.
- b. Set the control levers on the control boxes to OFF.
- c. Start the vehicle engine and run at a fast idle speed (approx. 1250 rev/min) and pull the compressor switch to the ON position.

#### Note...

Although it is by no means essential, if the compressor switch is set to the OFF position whenever the vehicle engine is not running, this will ensure that the vehicle starter motor is not over-worked when starting the engine.

- d. Allow air pressure to build up, checking that the warning buzzer operates until system pressure exceeds 4.0 bar (60 lbf/sq in) indicated on the pressure gauge in the driver's cab, then ceases to operate.

#### Note...

Once pressure has exceeded 4.0 bar (60 lbf/sq in) the system may be used, but where time permits, it is better to allow the system to reach its nominal operating pressure of 7.1 bar (100 lbf/sq in) before use.




Fig.21 Norgren filters

- 1 Special carbon filter
- 2 Valve cap nut
- 3 Drain valve
- 4 Purair filter

- e. Connect the required number of patient hoses and face masks to the appropriate control box hose connections for the stretcher positions to be used.
- f. Set the control lever on the appropriate control box(es) to AIR and check that system pressure is registered on the gauge (1).
- g. Check that a supply of air is reaching the required face masks by placing a hand over the mask and feel for air pulsations.
- h. Set the control lever(s) on the control box(es) to OFF until required for use.
- i. When ready for use, set the control lever(s) to AIR and place the face mask over the patient's nose and mouth.

#### Closing Down the Resuscitation System

84. Assuming that all patients have been removed, proceed as follows:-

- a. Ensure that the control lever(s) on the control box(es) are set to OFF.
- b. Push the compressor switch to the OFF position.
- c. Set the control lever on one of the control boxes to OXYGEN, note the pressure on the gauge then set the control lever to OFF.

- d. At the oxygen cylinder, using the key stowed adjacent to the cylinder, turn the valve on the neck of the cylinder OFF.
- e. Set the control levers on the control boxes to OXYGEN note that the pressure gauges fall to zero, indicating that the system has been exhausted of oxygen.
- f. Whilst there is still sufficient air pressure in the system, carry out the following drainage procedure:-

CAUTION...

Protect eyes from residue being forced out under pressure from the drain valve.

- (1) At the Norgren filters, hold a suitable container under the drain valve (Fig 21 (3)), then slowly unscrew the plastic valve cap nut (2) 1/2 to 1 turn until air and sediment issues from the drain port

Note...

Keep fingers clear of the port.

- (2) When emission of oil and water residue ceases, half tighten the valve cap sufficiently to ensure an airtight seal. DO NOT OVERTIGHTEN.
- (3) Using a clean dry piece of cloth, wipe the filter clean.

Note...

The filter and air reservoir must be drained after each operation of the equipment.

- (4) At the left-hand side of the vehicle outside below the battery stowage compartment, locate and pull the air tank vent lever (Fig 9 (7)) to drain the reservoir.
- (5) Set the control levers on the control boxes to AIR to exhaust the residual air from the system through the face masks.

Note...

If an odour is detected in this filtered air, the special carbon filter cartridge requires replacement REPORT.

- (6) Check that the control box pressure gauges fall to zero, then set the control levers to OFF.

- (7) Ensure that the Norgren filter and air reservoir drain valves are closed.
- g. Clean the face masks and patient valves and sterilise before disconnecting, then place them in plastic bags and stow.

Note...

It may be necessary to decontaminate masks etc., if they have been used in an NBC environment.

- h. If the pressure indication of the oxygen cylinder previously noted, necessitates, change the oxygen cylinder as detailed in para. 85.

CHANGING OXYGEN CYLINDER (Fig.22)

85. Two types of regulator valve assemblies are available for use; the older type requires the use of a spanner to fit to, or remove from a cylinder, the newer type has a plastic-covered connecting nut (Fig 22) with finger grips.


Note...

A spanner, for use with older type regulators is stowed with the valve key, adjacent to the cylinder.

WARNING...

HIGH PRESSURE OXYGEN SUPPLY. DO NOT ALLOW OILS, GREASES, NAKED FLAMES OR EXPOSED FILAMENTS NEAR OXYGEN EQUIPMENT.

- a. Ensure that the valve (4) in the neck of the cylinder is fully closed, and that all residual oxygen in the system has been exhausted (refer to para. 84).
- b. Unscrew and remove the regulator valve assembly from the cylinder, by either unscrewing the large plastic covered nut (3) or by using the spanner on the union nut.
- c. Remove the protective transit cap (6) from the second cylinder, then fit the regulator assembly to the second cylinder and tighten either by hand or using the spanner. Replace the spanner in its stowage.



- 1 Cylinder pressure gauge
- 2 Delivery hose
- 3 Plastic covered nut
- 4 Valve
- 5 Cylinder key
- 6 Transit cap

**Fig 22 Oxygen cylinder regulator valve assembly**

- d. Open the valve in the neck of the cylinder. Check the contents available in the bottle on the gauge on the regulator valve assembly.
- e. Set the control levers on the control boxes to OXYGEN. Note the pressure on the control boxes gauges and check the face masks for correct operation.
- f. Set the control levers to OFF. Turn off the cylinder valve. Set the control levers to OXYGEN to exhaust the residual gas from the system, note the pressure gauges return to zero. Set the control levers to OFF.
- g. As soon as possible, replace the empty cylinder with a full one.



**CONNECTING AND DISCONNECTING FACE MASKS**

86. The procedure for connecting and disconnecting face masks is as follows:-

a. Connecting

(1) Push the cone ended adaptor on the patient hose into the appropriate hose connector (Fig 20(2)) on the control box.

(2) Lightly pull on the hose to check for security of attachment.

b. Disconnecting

(1) Lift the outer knurled sleeve of the mask connector (Fig 20(4)) and the cone ended adaptor will be ejected.

▶ **DISASSEMBLING FACE MASK VALVE (Fig 23)**


87. The valve must be disassembled and cleaned after use, or if not working satisfactorily. A multi-purpose spanner, which is clipped to each face mask hose should be used. The procedure is as follows:-

a. Remove and extract the piston and main spring (2) as an assembly. Do not attempt to separate.

b. Unscrew the safety relief valve (7) using the spanner on the hexagonal portion of the valve body.

c. Clean and sterilise all parts as necessary.

d. Dry thoroughly, then re-assemble ensuring that there is no ingress of foreign matter. ◀



U446

- 1 Anti-inhalation valve
- 2 Piston and spring assembly
- 3 Valve body
- 4 Hose (from central box)

- 5 Face mask retaining nut
- 6 Face mask
- 7 Relief valve

Fig 23 - Face mask valve

**ARMY CODE No 24044**

**AIR PUBLICATION 5102A (UH)**

## Section 3

## Chapter 1

## User Servicing and adjustments

LUBRICATION


88. a. Apply a few drops of oil to the rear door opening mechanism and hinges, bodyside hinges and latches, rear step mechanism and hinges, stretcher clamp pivot bolts, bodyside and roof flaps hinges and escape hatch mechanism.
- b. Apply grease to each stretcher lift mechanism. Three grease nipples are provided for each mechanism.


CHANGING LAMPSMap Reading Light

89. To change a lamp in the map reading light (Fig 24), ensure that the control switch is set to OFF. Remove the screw securing the metal cover and glass, remove the defective lamp and replace. Finally re-assemble the light.

Fig.24 Map reading light

- 1 Lamp
- 2 Glass cover
- 3 Metal cover
- 4 Securing screw





- 1 Lamp
- 2 Lamp cover

Fig.25 Cab Light

#### Cab Light


90. To change a lamp in the cab light (Fig 25), ensure the control switch is set to OFF. Press the long sides of the covers inwards. Remove the cover, the lamp is then readily accessible and can be replaced. Finally, press the cover back in position.

#### Casualty Compartment Light

91. To replace the lamps in the casualty compartment (Fig 26). Ensure the control switch is set to OFF. Remove the screws securing the cover, the lamps are then readily accessible and can be replaced. Finally, secure the cover in place.

Fig. 26 Casualty compartment light

- 1 Lamp
- 2 Securing screw
- 3 Lamp cover




#### Casualty Compartment Blackout Light

92. To replace the lamps in the casualty compartment blackout light (Fig 27). Remove the screws securing the blue glass cover, the lamps are then readily accessible and can be replaced. Finally, secure the cover in place.


Fig. 27 Casualty compartment blackout light

- 1 Lamp
- 2 Securing screw
- 3 Cover




#### Rotating Beacon

93. To replace the lamp in the older type rotating beacon (Fig 28) Remove the weather seal, slacken the securing screw, lift off the b cover, leaving the lamp readily accessible for replacement. Repla the blue cover and tighten the securing screw. Finally, replace t weather seal.

Newer Type

- 1 Blue cover
- 2 Securing screw
- 3 Lamp

Older Type

- 1 Weather seal
- 2 Blue cover
- 3 Lamp
- 4 Securing screw

Fig.28 Rotating beacon (alternative types)

To replace the lamp in the new type rotating beacon (Fig 28). Remove the blue cover, unscrew the securing screw, leaving the lamp readily accessible for replacement. Replace the securing screw. Finally replace the blue cover.

Front fog light


94. To replace a lamp in the front fog light (Fig 29). Remove the two screws securing the cover, disconnect the lamp lead. Remove the spring/wire retainer, remove the unserviceable lamp and replace with a new one. Secure the lamp to the reflector with the spring wire retainer, re-connect the lamp lead. Finally, secure the cover in place.

Note...

Do not touch replacement lamp with bare fingers.

Fig.29 - Front fog light

- 1 Securing screw
- 2 Cover
- 3 Reflector
- 4 Spring wire retainer
- 5 Lamp



### Rear Fog Light

95. Unscrew the red cover, the lamp is readily accessible and can be replaced. Finally, screw the cover back in place.

### Rear Compartment Wander Light

96. Remove the rubber retaining ring and the wire grill, the lamp is readily accessible and can be replaced. Finally, replace the wire grille and rubber retaining ring.

### RESUSCITATION SYSTEM

97. Daily after use and at prescribed vehicle servicing intervals, the resuscitation system is to be tested, following the instructions detailed in Chapter 2, Special Instructions, of this Section.

### AIR COOLING SYSTEM (RAF vehicles only)

98. At the prescribed intervals, or more frequently if the vehicle is driven through dusty environments or through swarms of insects, carry out the following:-

#### a. Condenser

- (1) Remove all foreign matter such as leaves and insects from around the tubes and between the fins and intake grille to ensure a free circulation of air.



- b. Evaporator
  - (1) Remove all foreign matter from around the tubes and fins of the heat exchanger and intake grille to ensure a free circulation of air.
  - (2) Examine fan blades for wear, damage, abrasion and cleanliness.
  - (3) Clean the fan blades to prevent them from becoming unbalanced.
  - (4) Remove the foam filter element, wash with warm soapy water, rinse, dry and replace.
- c. Wiring
  - (1) Examine all visible wiring for signs of wear and abrasion.
- d. Hoses
  - (1) Examine all hoses for wear. Excessively worn hoses are to be replaced. Re-route the hose to avoid further wear.
  - (2) Examine hose clips and ensure that clips have not been overtightened.
- e. Filter Drier
  - (1) Operate system for several minutes and check refrigerant level indication in sight glass. Bubbles or foam in the refrigerant indicate that the level is low. Check system carefully for leaks. Rectify any faults found and re-charge the system.
- f. Thermostat Check
  - (1) Operate the system, set the temperature control to a higher temperature than that inside the rear compartment.
  - (2) Ensure that the electro-magnetic clutch has disengaged and cooling has terminated.
  - (3) Set the temperature control to a lower temperature than that inside the rear compartment and ensure that the cooling system cuts in again.

99. Any undue noise or vibration must be investigated immediately. The causes vary and can be mechanical, electrical or associated with the refrigeration system.


## Section 3

## Chapter 2

## Special Instructions

**TESTING RESUSCITATION SYSTEM****GENERAL**

100. The test set (Fig 30) has been designed to test the pressure and tidal volume delivered to each face mask quickly. The test set comprises a test lung and a pressure test gauge. Both the test lung and pressure gauge are attached in turn to each face mask valve to check for the correct operation of the resuscitator.



- 1 Face mask valve
- 2 Lung inlet
- 3 Indicator arm

- 4 Volume scale arm
- 5 Green sector
- 6 Lung
- 7 Test set

- 8 Green segment on pressure gauge
- 9 Pressure gauge
- 10 Gauge inlet

**Fig 30 - Resuscitation system test set**

101. The valve is functioning satisfactorily when the test lung indicator arm rises to within the green sector on the volume scale arm and when the pointer on the pressure gauge registers with the green segment on the gauge scale.

## TEST PROCEDURE

102. The tests must be carried out on both air and oxygen systems. The procedure for each system is similar. The test described in the following paragraphs are for the oxygen system, when the air system is tested, the only difference being that instead of setting the control lever on the control unit to OXYGEN, it should be set to AIR.

### Note

Although the procedures are intended primarily to check the function of the resuscitator module and face mask valve, they will also indicate the presence of a serious supply failure in the circuit.

#### a. Pressure Test

- (1) Remove the face mask from the valve.
- (2) Connect the valve hose to one of the connections on one of the control units.
- (3) Connect the corrugated tube from the pressure test gauge to the face mask valve outlet.
- (4) Using the key stowed adjacent to the oxygen cylinder, turn the cylinder valve on and check the pressure of oxygen available from the cylinder.
- (5) Set the control lever on the control unit to OXYGEN and note that oxygen supply pressure is indicated on the control unit pressure gauge.
- (6) At the pressure test gauge ensure that the output pressure during inspiration registers within the green segment (480mm w.g. to 720mm w.g) and at the same time the audible alarm sounds.
- (7) If the indicated pressure is outside the segment, check all connections to ensure that there are no leaks. If no leaks are present, a fault is indicated. Report any faults immediately.
- (8) On completion of this test with each face mask valve and all outlets from the control units, start the vehicle's engine; allow the air pressure system to build up to a maximum working pressure - 7.1 bar (100lbf/sq in) - set the control lever on the control unit to AIR and repeat the pressure gauge test.

## b. Flow Test

- (1) Remove the pressure test gauge from the face mask valve outlet and connect the valve outlet to the red plastic inlet of the test lung ensuring that the pressure relief valve on the face mask valve is vertical and that the test lung is supported on a firm horizontal flat surface.
- (2) Raise the volume scale arm by its red knob, to its fullest extent.
- (3) Set the control lever on the control unit to OXYGEN and allow the test lung to cycle two or three times, after which the indicator arm should be within the green sector on the volume scale 990 to 1210 ml). If the arm is outside the green sector, this is an indication of a fault and must be reported immediately.
- (4) The first inflation of the lung will cause the indicator arm to rise and it should subsequently rise to the same level each time.
- (5) Using a stop watch, check the frequency at which the test lung operates. The correct frequency is 12.6 to 15.4 cycles per minute. Any frequency outside these limits indicates a fault which must be reported immediately.

## Note . . .

When the timing starts, the first pulse should be counted as zero.

- (6) This paragraph deleted by Amdt 2.
- (7) On completion of these tests at all outlets from the control units, set the control levers on the control units to AIR and repeat the tests.
- (8) On completion of all tests, re-connect the face masks to the valve outlet and stow the face mask valve assembly and hose.
- (9) Switch off the vehicle's engine and drain the air from the system.
- (10) Turn the oxygen cylinder valve off and exhaust the residual oxygen from the system.

**PREPARATION FOR SEA OR AIR TRANSPORTATION**

103. Carry out the following operations:-

- a. Remove the front fog lights from the mounting brackets on each side of the vehicle.
- b. Remove the beacon light from the mounting on the roof. On RAF vehicles, remove the roof-mounted aerial.
- c. Remove the silica gel desiccator from each double glazed window in the rear doors and the rear compartment side walls.

**SLINGING POINTS**

104. Slings points in the form of four bow-spring shackles are provisioned and positioned at the front and rear of the vehicle.

**TIE-DOWN POINTS**

105. Tie-down points for securing the vehicle during land, sea or air transportation are provided by the two forward slinging bow-spring shackles and a large tie-down bracket attached to the rear chassis frame.

**DO'S AND DONT'S**

106.
  - a. Do switch on the Eberspacher heater and operate briefly once a month during warm weather.
  - b. Do switch off the Eberspacher master heater when adding fuel.
  - c. Do ventilate the interior of the whole vehicle after using fire extinguishers.
  - d. Do drain the resuscitation system after use.
  - e. Do change NBC filter cartridges if used in an NBC environment.
  - f. Do carry out the Test Set checks after use of resuscitation system.
  - g. Do keep face masks clean and in a sterilised condition.
  - h. Do not operate the Eberspacher heater in a garage.
  - i. Do not switch the Eberspacher heater ON and OFF more than twice more if the heater fails to ignite at the first attempt.
  - j. Do not allow oxygen cylinders to become completely discharged.

## Section 4

## Destruction of Equipment

GENERALDestruction

107. Destruction of the equipment, when subject to capture or abandonment in the combat zone, will be undertaken by the Us Arm.

Degree of damage

108. Methods of destruction should achieve such damage to equipment and essential spare parts that it will not be possible to repair the equipment to a usable condition in the combat zone either by repair or by cannibalization.

109. Classified equipment must be destroyed in such degree as to prevent, whenever possible, duplication by, or revealing means of operation or function to the enemy.

Priorities for destruction

110. Priority must be given to the destruction of classified equipment and associated documents.

111. When lack of time and/or stores prevents complete destruction of equipment, priority is to be given to the destruction of essential parts, and the same parts are to be destroyed on all like equipment.

112. A guide to priorities for the destruction of the equipment is shown below.

| Parts                       | Priority |
|-----------------------------|----------|
| Tyres, wheel and suspension | 1        |
| Braking system              | 2        |
| Frame                       | 3        |